

Ingeo Biopolymer 3D870 Technical Data Sheet

3D Printing Monofilament – High Heat and Impact Grade

Monofilament Applications

Ingeo 3D870 is a grade developed for manufacturing 3D printer monofilament. Engineered to deliver improved heat-resistance and high impact strength to 3D printed parts, this formulated grade achieves thermal and mechanical properties similar to ABS while offering an alternative to styrenic-based materials. Monofilaments made with Ingeo 3D870 provide excellent 3D printing characteristics such as precise detail, good adhesion to build plates, less warping or curling, and low odor.

PHYSICAL PROPERTIES ⁽¹⁾	3D870	ASTM METHOD
Specific Gravity, g/cc	1.22	D792
MFR, g/10 min ⁽²⁾	9-15	D1238
Peak Melt Temperature, °C	165-180	D3418
Glass Transition Temperature, °C	55-60	D3418

(1) Typical properties; not to be construed as specifications.

(2) 210° C/2.16 kg

MECHANICAL PROPERTIES ⁽³⁾	XY AXIS	YX AXIS	ZX AXIS	ASTM METHOD
Tensile Strength, psi (MPa)	5,802 (40)	4,641 (32)	3,481 (24)	D638
Tensile Modulus, kpsi (MPa)	416 (2,865)	355 (2,447)	359 (2,477)	D638
Flexural strength, psi (MPa)	10,588 (73)	7,106 (49)	6,672 (46)	D790
Flexural modulus, kpsi (MPa)	350 (2,414)	287 (1,979)	341 (2,352)	D790
Notched Izod Impact [amorphous], ft-lb/in (J/m)	2.99 (160)	2.26 (21)	2.04 (109)	D256
Notched Izod Impact [crystalline], ft-lb/in (J/m)	4.37 (233)	3.74 (200)	1.19 (64)	D256
Heat Distortion Temperature (°C) 66 psi (0.45 MPa)		75-85		E2092

(3) All 3D printed parts printed at 100% infill and annealed at 110°C/20 min unless otherwise noted. Bars printed and tested by [Essentium Materials](#).

PROCESSING TEMPERATURE PROFILE ⁽⁴⁾	ENGLISH	METRIC
Melt Temperature	410°F	210°C
Feed Throat	113°F	45°C
Feed Temp.	355°F	190°C
Compression Section	375°F	200°C
Metering Section	390°F	210°C
Adapter	390°F	210°C
Die	390°F	210°C
Screw Speed	20-150 rpm	
Filament Diameter Inspection (on-line)	Essential for quality monofilament (+/- 3% max. deviation)	
3D Printing Temperature	190-230°C	
Annealing Temperature	110-120°C	
Print Bed Temperature	None needed (or 50-70°C if applicable).	

(4) Starting points only, and may need to optimized depending on your system.

Processing Information

Ingeo 3D870 is available in pellet form. This formulated grade can be used in applications requiring crystalline engineered compounds where nucleants, modifiers, process aids, and reinforcing agents, etc. may be added, per end-use requirements. Drying prior to processing is essential. The polymer is stable in the molten state, provided that the extrusion and drying procedures are followed. Post-annealing in the range of 176-266°F (80-130°C) can be used to promote crystallization and improve the heat deflection temperature of the 3D printed part.

Machine Configuration

Ingeo polymers will process on conventional extruders using general purpose screws with L/D ratios from 24:1 to 30:1 and compression ratio of 2.5:1 to 3:1. Smooth barrels are recommended. Optimization to your specific equipment may require NatureWorks technical support.

Process Details

Startup and Shutdown

Ingeo 3D870 is not compatible with a wide variety of resins, and special purging sequences should be followed:

1. Clean extruder and bring temperatures to steady state with low-viscosity, general-purpose polystyrene or high MFR polypropylene.
2. Vacuum out hopper system to avoid contamination.
3. Introduce Ingeo polymer into the extruder at the operating conditions used in Step 1.
4. Once Ingeo polymer has purged, reduce barrel temperatures to desired set points.
5. At shutdown, purge machine with high-viscosity polystyrene or polypropylene.

Drying

In-line drying is required. A moisture content of less than 0.025% (250ppm) is recommended to prevent viscosity degradation. Typical drying conditions are 8 hours at 122F (50°C) or to a dew point of -30°F (-35°C), with an airflow rate greater than 0.5 cfm/lb. of resin throughput. The resin should not be exposed to atmospheric conditions after drying. Keep the package sealed until ready to use and promptly reseal any unused material.

Annealing Printed Parts

Ingeo 3D870 is formulated to crystallize when annealed post-printing. Crystallization is a simple and effective route to improve the thermal performance and further enhance the impact properties of Ingeo 3D870. The recommended anneal temperature is in the range of 110°C-120°C. Annealing can be carried out in an oven or some other medium of heat-transfer, such as a hot-water bath. Make sure to follow safety procedures that are appropriate for working around elevated temperatures. Below is a general guideline to anneal parts printed with Ingeo 3D870:

1. Pre-heat oven to an anneal temperature range of (110°C-120°C).
2. Measure temperature at various locations in the oven to ensure absence of hot/cold spots. Uneven heating can lead to unexpected warpage and sub-optimal performance of the part
3. Place printed part in oven and start timer. Typical time to anneal parts with wall-thickness of 0.125 in (~3.18 mm) is around 20 minutes, but this time is dependent on wall thickness.
4. For large dimension parts, it is common to use support fixtures (e.g.-aluminum jigs) during the annealing process
5. Once removed from the oven, let the part cool in ambient conditions. Minimize handling, as inside of the part will likely remain at elevated temperatures longer than the outside.
6. If using a water-bath to anneal, the part may have to be at temperature for a slightly longer time to crystallize (since the water-bath cannot be at 110°C-120°C).
7. Measure dimensions of the part prior to annealing and again after, to determine shrink.

Food Packaging Status

This grade is not certified for food contact applications

Bulk Storage Recommendations

The resin silos recommended and used by NatureWorks are designed to maintain dry air in the silo and to be isolated from the outside air. This design would be in contrast to an open, vented to atmosphere system that we understand to be a typical polystyrene resin silo. Key features that are added to a typical (example: polystyrene) resin silo to achieve this objective include a cyclone and rotary valve loading system and some pressure vessel relief valves. The dry air put to the system is sized to the resin flow rate out of the silo. Not too much dry air would be needed and there may be excess instrument air (-30°F dew point) available in the plant to meet the needs for dry air. Our estimate is 10 scfm for a 20,000 lb/hr rate resin usage. Typically, resin manufacturers specify aluminum or stainless steel silos for their own use and avoid epoxy-lined steel.

Safety and Handling Considerations

Safety Data Sheets (SDS) for Ingeo biopolymers are available from NatureWorks. SDS's are provided to help customers satisfy their own handling, safety, and disposal needs, and those that may be required by locally applicable health and safety regulations. SDS's are updated regularly; therefore, please request and review the most current SDS's before handling or using any product.

The following comments apply only to Ingeo biopolymers; additives and processing aids used in fabrication and other materials used in finishing steps have their own safe-use profile and must be investigated separately.

Hazards and Handling Precautions

Ingeo biopolymers have a very low degree of toxicity and, under normal conditions of use, should pose no unusual problems from incidental ingestion or eye and skin contact. However, caution is advised when handling, storing, using, or disposing of these resins, and good housekeeping and controlling of dusts are necessary for safe handling of product. Pellets or beads may present a slipping hazard.

No other precautions other than clean, body-covering clothing should be needed for handling Ingeo biopolymers. Use gloves with insulation for thermal protection when exposure to the melt is localized. Workers should be protected from the possibility of contact with molten resin during fabrication.

Handling and fabrication of resins can result in the generation of vapors and dusts that may cause irritation to eyes and the upper respiratory tract. In dusty atmospheres, use an approved dust respirator.

Good general ventilation of the polymer processing area is recommended. At temperatures exceeding the polymer melt temperature (typically 175°C), polymer can release fumes, which may contain fragments of the polymer, creating a potential to irritate eyes and mucous membranes. Good general ventilation should be sufficient for most conditions. Local exhaust ventilation is recommended for melt operations. Use safety glasses (or goggles) to prevent exposure to particles, which could cause mechanical injury to the eye. If vapor exposure causes eye discomfort, improve localized fume exhausting methods or use a full-face respirator.

The primary thermal decomposition product of PLA is acetaldehyde, a material also produced during the thermal degradation of PET. Thermal decomposition products also include carbon monoxide and hexanal, all of which exist as gases at normal room conditions. These species are highly flammable, easily ignited by spark or flame, and can also auto ignite. For polyesters such as PLA, thermal decomposition producing flammable vapors containing acetaldehyde and carbon monoxide can occur in almost any process equipment maintaining PLA at high temperature over longer residence times than typically experienced in extruders, fiber spinning lines, injection molding machines, accumulators, pipe lines and adapters. As a rough guideline based upon some practical experience, significant decomposition of PLA will occur if polymer residues are held at temperatures above the melting point for prolonged periods, e.g., in excess of 24 hours at 175°C, although this will vary significantly with temperature.

Combustibility

Ingeo biopolymers will burn. Clear to white smoke is produced when product burns. Toxic fumes are released under conditions of incomplete combustion. Do not permit dust to accumulate. Dust layers can be ignited by spontaneous combustion or other ignition sources. When suspended in air, dust can pose an explosion hazard. Firefighters should wear positive-pressure, self-contained breathing apparatuses and full protective equipment. Water or water fog is the preferred extinguishing medium.

Ingeo Biopolymer 3D870 Technical Data Sheet

Foam, alcohol-resistant foam, carbon dioxide or dry chemicals may also be used. Soak thoroughly with water to cool and prevent re-ignition.

Disposal

DO NOT DUMP INTO ANY SEWERS, ON THE GROUND, OR INTO ANY BODY OF WATER. For unused or uncontaminated material, the preferred option is to recycle into the process otherwise, send to an incinerator or other thermal destruction device. For used or contaminated material, the disposal options remain the same, although additional evaluation is required. Disposal must be in compliance with Federal, State/Provincial, and local laws and regulations.

Environmental Concerns

Generally speaking, lost pellets, while undesirable, are benign in terms of their physical environmental impact, but if ingested by wildlife, they may mechanically cause adverse effects. Spills should be minimized, and they should be cleaned up when they happen. Plastics should not be discarded into the environment.

Product Stewardship

NatureWorks has a fundamental duty to all those that use our products, and for the environment in which we live. This duty is the basis for our Product Stewardship philosophy, by which we assess the health and environmental information on our products and their intended use, and then take appropriate steps to protect the environment and the health of our employees and the public.

Customer Notice

NatureWorks encourages its customers and potential users of its products to review their applications from the standpoint of human health and environmental quality. To help ensure our products are not used in ways for which they were not intended or tested, our personnel will assist customers in dealing with ecological and product safety considerations. Your sales representative can arrange the proper contacts. NatureWorks literature should be consulted prior to the use of the company's products.

NOTICE:

No freedom from infringement of any patent owned by NatureWorks LLC or others is to be inferred. No information in this publication can be considered a suggestion to infringe patents.

The technical information, recommendations and other statements contained in this document are based upon tests or experience that NatureWorks believes are reliable, but the accuracy or completeness of such information is not guaranteed. Many factors beyond NatureWorks control can affect the use and performance of a NatureWorks product in a particular application, including the conditions under which the product is used and the time and environmental conditions in which the product is expected to perform. Since these factors are uniquely within the user's knowledge or control, it is essential that the user evaluate the NatureWorks product to determine whether it is fit for a particular purpose and suitable for the user's method of application. In addition, because use conditions are outside of NatureWorks control and applicable laws may differ from one location to another and may change with time, Customer is solely responsible for determining whether products and the information in this document are appropriate for Customer's use and for ensuring that Customer's workplace, use and disposal practices are in compliance with applicable laws and regulations. NatureWorks LLC assumes no obligation or liability for the information in this document.

NATUREWORKS MAKES NO WARRANTY, EXPRESS OR IMPLIED, REGARDING THE INFORMATION CONTAINED HEREIN OR ITS PRODUCTS, INCLUDING BUT NOT LIMITED TO ANY WARRANTY AS TO ACCURACY OR COMPLETENESS OF INFORMATION, OR ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

WARNING REGARDING MEDICAL APPLICATIONS

NatureWorks products are not designed or manufactured for medical applications ("Medical Applications"), including without limitation, any commercial or developmental applications intended:

Ingeo Biopolymer 3D870 Technical Data Sheet

- (a) For implantation in the human body or contact with human internal body fluids or body tissues, regardless of the length of time involved;
- (b) As a critical component of any medical device that supports or sustains human life; or
- (c) For use specifically by pregnant women or in any applications designed specifically to promote or interfere with human reproduction.

NATUREWORKS MAKES NO REPRESENTATION, PROMISE, EXPRESS WARRANTY OR IMPLIED WARRANTY THAT NATUREWORKS PRODUCTS ARE BIO-COMPATIBLE OR OTHERWISE FIT FOR MEDICAL APPLICATIONS. DO NOT USE NATUREWORKS PRODUCTS FOR MEDICAL APPLICATIONS unless the products have been provided from NatureWorks under a written contract that expressly approves the contemplated use. NatureWorks has no specific expertise in Medical Applications and does not perform testing, clinical studies or investigations of the suitability of its products for specific Medical Applications. Do not rely on NatureWorks to determine if a NatureWorks product is suitable for a Medical Application. Any customer or downstream user of NatureWorks Products is solely responsible for determining whether the product is safe, lawful and technically suitable for its intended use, and for conducting their own studies, registrations and other activities to establish the safety, regulatory compliance and efficacy of their products.

NOTICE REGARDING PROHIBITED USE RESTRICTIONS: Unless specifically agreed to in writing by NatureWorks, NatureWorks LLC will not knowingly sell or sample any product into any of the following commercial or developmental applications (i) components of or packaging for tobacco products, (ii) components of products intended for human or animal consumption, (iii) any application that is intended for any internal contact with human body fluids or body tissues, (iv) as a critical component in any medical device that supports or sustains human life, (v) in any product that is designed specifically for ingestion or internal use by pregnant women, (vi) in any application designed specifically to promote or interfere with human reproduction, (vii) in microbeads, including those used in personal care/cosmetic applications, or (viii) to manufacture bottles or bottle pre-forms in North America.

For additional information please contact NatureWorks via our [website](http://natureworkslc.com/contact-us) at natureworkslc.com/contact-us.



15305 Minnetonka Blvd., Minnetonka, MN 55345